

Revealing Interfaces and Nanostructure: The Application of Atom Probe Tomography to Nickel Based Superalloys

Dr. Chantal Sudbrack, NASA Glenn Research Center, chantal.k.sudbrack@nasa.gov

1. Background in nickel-based superalloys
2. Background in atom-probe tomography
3. Decomposition behavior of model Ni-Al-Cr alloy when aged at 600 °C

Acknowledgements: Prof. David Seidman, Kevin E. Yoon , Zugang Mao (Northwestern); Ronald Noebe (NASA GRC); Georges Martin (Comm. à l'Energie Atomique); Northwestern University Center for Atom Probe Tomography (NUCAPT)

Poster: The effect of prior exposures on the notched fatigue behavior of disk superalloy ME3


Co-authors: Susan L Draper¹, Timothy T Gorman², Jack Telesman¹, Timothy P Gabb¹, David R Hull¹, Daniel E Perea³ and Daniel K Schreiber³ : 1. NASA Glenn 2. NASA USRP 3. PNNL



Ni-Based Superalloys

Due to an unusual combination of properties, Ni-based superalloys are used in many applications which require structural integrity at elevated temperatures

Precipitate strengthened




Mechanical properties

- Capable of bearing loads at $T/T_M = \sim 0.85-0.9$ ($T_{M(Ni)} = 1453^\circ\text{C}$) without significant deformation
 - γ' strengthening (precipitate strengthening)
 - Solid solution strengthening in the γ -matrix
- Damage Tolerance (Ductility and Toughness)

Requirements:

- Resistance to Environmental Degradation
 - Hot corrosion and oxidation

Turbine Jet Engine




Titanium Steel Nickel

- **Single Crystal Ni-Based Superalloys**

- Engineered for Extreme Temperature Capability - Creep, Thermal Fatigue and Environmental Protection
- Anisotropic Properties
- Turbine Blade and Nozzle Applications


NASA GRC



- **Polycrystalline Ni-Based Superalloys**


- Intermediate Temperature Capability – Fatigue, Tensile, Crack Growth and Environmental Resistance
- Isotropic Properties
- Turbine Disk Applications


NASA GRC



- **Model Ni-Based Superalloys**

- Fundamental thermodynamic and kinetic underpinning of γ' -precipitation





Atom-probe tomography measurements

APT: post-mortem atomic imaging technique in direct space with sub-nanometer spatial resolution (static snapshots of dynamic process)

1. Short-range ordering, clustering, impurity concentration & distribution

2. Morphological development


3. Dimensional and nanostructural quantification

- Variations in layer thicknesses
- Radius, number density, volume fraction of precipitates

4. Compositional characterization

- Bulk phases
- Fine scale nanostructure
- Buried interfaces (e.g. grain boundaries):
 - Chemical interdiffusion, chemical roughness, segregation, transients

~50 million atoms



3-D Atom Probe Tomography

Local Electrode Atom Probe (LEAP™) Imago Scientific 3000XSi




- Analyze data with 3D visualization software, IVAS, from Cameca (formerly Imago Scientific)

Determines the spatial position of individual atoms and their chemical identities with sub-nanometer scale resolution


Ion detection efficiency: 40-60%, Depth positioning: 0.02-0.05 nm, Lateral positioning: 0.2-0.3 nm

- Analyze volumes $>10^6 \text{ nm}^3$
 $0.1 \times 0.1 \times 0.5 \text{ } \mu\text{m}^3$
- 5×10^{-11} torr ultrahigh vacuum
- Specimen T : 20 to 300 K
- Equipped with both electrical and thermal-assisted pulsing:
 - 250 kHz electrical pulse
 - 500 kHz picosecond laser(green: 532 nm, 10 ps)



APT specimens are needle shaped


Metals: Electrochemical wire sharpening from APT blank (0.25 x 0.25 x 10 mm³)




D. A. Shashkov, M. F. Chrisholm and D. N. Seidman
Acta. Mater., 47, 3939-3951 (1999).

Nanowires: Direct growth on a micropost



Silicon Micropost Array




Perea et al. J. Solid State Chem., 181 (2008) 1642



Multilayers: FIB preparation / Lift-out to micropost





Pulsed-laser Atom Probe Tomography



Courtesy of NUCAPT

Ions identified from their m/n signature (time-of-flight)




PL-APT Mass Spectrum for a Commercial Ni-based Superalloy

3-D LEAP™ Tomography


Specimens & Pucks




Specimen Carousel




**Load Lock Chamber
(Top Entry)**




**Analysis Chamber
(Side Viewport)**



Needle Geometry



Microtip Geometry




- 4X4 array
- FIB Sharpened

Courtesy of NUCAPT


Courtesy of Imago

www.nasa.gov




Fine scale microstructural analysis with APT


Ni-5.2 Al-14.2 Cr (at. %) aged at 600°C for 4 hours



**APT
reconstructed
volume**



**Isoconcentration
surface**



**Selected
volume**

● Al atoms ● Cr atoms  9 at. % Al isoconcentration surface

Proximity Histogram Concentration Profile


Data analysis in IVAS 3D visualization software



Proximity Histogram or “Proxigram” is a 3D nonlinear compositional profile with respect to isoconcentration surface (interfaces).

Three steps

1. A sampling to generate a regular grid of concentration points
2. An interpolation to identify an isoconcentration surface
3. A correlation of the isoconcentration surface to the original set of discrete atomic positions





- Analyzes all the concentrations of the same value in a data set in parallel, invaluable for large data sets
- Invariant to interfacial geometry

Hellman, Seidman et al. *Micro. Microanal.* **6**, 437 (2000)



Decomposition behavior of model Ni-Al-Cr alloy when aged at 600 °C







T= 600 °C aging studies of Ni-5.2 Al-14.2 Cr at. %

Atomic-scale mechanisms that drive the early stage precipitation

Moderate solute
supersaturations,
 $\phi^{eq} = 15.6\%$
(nondilute, nonideal)



1st-order
ordering
transformation



Nanostructural & Compositional Evolution


Atom Probe

Lattice Kinetic
Monte Carlo

Clusters to precipitates radii up to ~10 nm


Seminal research of Schmuck *et al.* (Phil. Mag. A **76**, 1997, p.527)
and Pareige *et al.* (Acta mat. **47**, 1999, p.1889)

Temporal evolution of γ' -precipitation in 3D



10 x 10 x 25 nm³ sub-volumes of APT reconstructions

9 at. % Al isoconcentration surfaces (atoms omitted for clarity)



Ni-5.2 Al-14.2 Cr aged at 600°C

- Precipitates as small as $R = 0.45$ nm are resolved, 20 detected atoms, which is close to lattice kinetic Monte Carlo (LKMC) predictions for critical nuclei size of 0.485 nm
- Dimensions and orientation of each precipitate are determined using best-fit ellipsoid
- Buried interfaces: generate average compositional profiles across the γ/γ' interfaces using proximity histogram compositional profiles



APT measurements of the mean precipitate radius


t (h)	Nb. of ppts. analyzed	$\langle R \rangle \pm \sigma$ (nm)
0.17	7.5	0.74 ± 0.24
0.25	74	0.75 ± 0.14
1	100	0.89 ± 0.14
4	173.5	1.27 ± 0.21
16	101	2.1 ± 0.4
64	46	2.8 ± 0.6
256	81	4.1 ± 0.8
1024	6	7.7 ± 3.3

nucleation

nucleation
and growth


growth and
coarsening

Growth regimes established by APT measurements



Example of γ' -precipitate pair connected by necked region

$t = 4 \text{ h}$ at peak N_v



Ppts. per unit volume (N_v)


Mean precipitate radius ($\langle R \rangle$)

Al and Cr atoms within the 9 at. % Al isoconcentration surface displayed

Sudbrack et al, Acta Mater 54 (2006) 3199


Concentration profile evolution in the matrix

Schematic: **Growth of stable nucleus** occurs by solute diffusion driven by **chemical potential gradient** due to supersaturated matrix




➡ Transients disappear after 16 h
 \therefore quasi-steady state obtained

F. S. Ham, *J. Phys. Chem. Solids*, 6 (1958) 335




* Proxigram method, which averages over all interfaces in the analysis volume www.nasa.gov 16

Compositional evolution





Sudbrack et al, *Acta Mater* 54 (2006) 3199.



Gibbs-Thomson effect: predicts an increase in solid-solubility at an interface due its curvature. It is non-negligible when precipitate dimensions are on the of the order capillary length, typically 1-2 nm

See: Sudbrack et al, *Acta Mater* 55 (2007) 119.

Confirmation of early-stage coagulation & coalescence





There are four $L1_2$ ordering variants

APB energy for two variants to join is 3-4 times larger than interfacial energy

--> Two precipitates must match variants to join

As much as 30% coalesced





- **Atom probe tomography is a powerful characterization technique**
- **The combined APT/LKMC approach has been particularly helpful in:**
 - Nanometer scale characterization of morphological development in 3D
 - Precise compositional analysis of buried interfaces
 - Insight into diffusional processes that drive phase transformations